



| Detail No. | Part Name                    | Part No. | Price | Detail No. | Part Name   | Part No. | Price |
|------------|------------------------------|----------|-------|------------|---|----------|-------|
| 1          | Crank Handle Pin             | SP1      | .60   | 33         | Pick-up housing lock washer                       | SP98     | .10   |
| 2          | Crank Handle                 | SP4      | .55   | 34         | Pick-up bail — with roller bearing & trip bracket | SPA2     | 2.25  |
| 3          | Crank Arm                    | SP7      | 1.35  | 35         | Bail bracket spring                               | SPA6     | .25   |
| 4          | Crank Arm Cover              | SP11     | .70   | 36         | Line roller sleeve                                | SPA9     | .55   |
| 5          | Non reverse lever screw      | SP15     | .10   | 37         | Line roller                                       | SPA11    | .70   |
| 6          | Non reverse lever            | SP16     | .20   | 38         | Trip bracket                                      | SPA13    | .75   |
| 7          | Non reverse bushing          | SP17     | .20   | 39         | Roller lock nut                                   | SPA17    | .30   |
| 8          | Ball bearing retaining Plate | SP18     | .20   | 40         | Bail bracket screw                                | SPA18    | .65   |
| 9          | Ball bearing plate screws    | SP21     | 3@.20 | 41         | Ball bearing                                      | SPA21    | 1.00  |
| 10         | Main shaft assembly          | SP22     | 1.40  | 42         | Pinion gear                                       | SPA24    | 4.25  |
| 11         | Pick-up housing              | SP26     | 3.25  | 43         | Drive gear washer                                 | SPA27    | .10   |
| 12         | Plunger spring               | SP30     | .10   | 44         | Drive gear  | SPA30    | 2.45  |
| 13         | Plunger                      | SP31     | .30   | 45         | Washer  | SPA34    | .10   |
| 14         | Plunger sleeve               | SP35     | .30   | 46         | Level wind lever for 935 & 960 bracket attached   | SPA38    | .65   |
| 15         | Trip bracket screw           | SP39     | .65   | 47         | Level wind/lever screw                            | SPA42    | .30   |
| 16         | Trip bracket washer          | SP42     | .20   | 48         | Level wind pin                                    | SPA46    | .10   |
| 17         | Pick-up housing nut          | SP45     | .16   | 49         | Cover plate                                       | SPA49    | 1.15  |
| 18         | Spool Shaft                  | SP48     | 1.25  | 50         | Cover plate screws                                | SPA53    | 2@.15 |
| 19         | Spool washer (thick)         | SP52     | .10   | 51         | Snap rings  | SPA54    | 2@.10 |
| 20         | Spool washer (thin)          | SP55     | .10   | 52         | Non reverse pawl spring                           | SPA55    | .10   |
| 21         | Spool                        | SP58     | 2.80  | 53         | Non reverse pawl                                  | SPA58    | .20   |
| 22         | Drag washers                 | SP62     | 3@.30 | 54         | Non reverse cam spring                            | SPA61    | .10   |
| 23         | Drag eared washer            | SP65     | .15   | 55         | Non reverse arm                                   | SPA64    | .20   |
| 24         | Retaining ring               | SP68     | .10   | 56         | Non reverse cam                                   | SPA67    | .20   |
| 25         | Drag button                  | SP71     | 1.15  | 57         | Non reverse washer                                | SPA70    | .20   |
| 26         | Drag keyed washer            | SP74     | 2@.25 | 58         | Frame   | SPA72    | 3.85  |
| 27         | Spool arbor                  | SP77     | .30   | 59         | Spool — complete with internal parts              | SPA76    | 6.00  |
| 28         | Click pawl                   | SP81     | .20   | 60         | Crank handle assembly                             | SPA80    | 3.25  |
| 29         | Click spring                 | SP85     | .10   |            |   |          |       |
| 30         | Click pawl screw             | SP89     | .20   |            |   |          |       |
| 31         | Bail stop screw              | SP90     | .10   |            |   |          |       |
| 32         | Bail stop                    | SP94     | .35   |            |   |          |       |